

# INOCare BRASS CLEANING BRUSH

The INOCare brass brush ensures an effective and gentle cleaning of our INOflex® anilox rollers and sleeves. The brush from our INOCare product range which was specially designed for chrome anilox rollers, cleans and maintains your roller surfaces in connection with our INOCare cleaners, thus ensuring a long service life and consistent quality.



## MATERIAL

- Handle made of high-quality wood
- Brush head made of stainless brass

## DIMENSIONS

- 107 mm x 64 mm

## AREAS OF APPLICATION

- Chrome rollers

## APPLICATION

Dilute INOCare Bioclean 2000 at a ratio of 1:10 with water, and evenly apply it to the surface to be cleaned with a spray bottle, and let it soak for five minutes. Afterwards clean the surface with the INOCare brass cleaning brush and wipe afterwards with a damp cloth and clean water.

Stand: 05/2016