

INOcare BIOCLEAN 2000

The powerful concentrated cleaning agent has been specially developed for the cleaning of ceramic and chrome anilox rollers, and is able to perform an effortless removal of inks as well as pigments, resin and glue materials from the cells based on water and solvents.



APPLICATION AREA

- Cleaning of anilox rollers

TEMPERATURE RANGE

- 5°C to 50°C

MIXING RATIO

- Can be diluted up to a ratio of 1:100

COLOR

- Yellowish green

PH-WERT

- 13-14

MARKING

- Labeling according to INOcare material safety data sheet
- Biodegradable in accordance with the Detergents Regulation

CHEMICAL BASIS

- Alkaline cleaner

CONTAINER SIZES

- 1 liter
- 10 liter
- 30 liter
- 200 liter
- 1000 liter

APPLICATION

Spray the surface to be cleaned, soak for a few seconds, then rinse with water. It can be used for strong soiling undiluted or diluted up to 1:100.

In high pressure cleaners it can be used at a ratio of 1:100 to 1:50.

With aluminum, first perform a cleaning test on a non-visible point. Do not permanently clean high-gloss painted surfaces, as this may lead to a fading of the surface. If necessary, carry out preliminary tests.

Stand: 05/2016